



ESCAPE V6

FORD

ARB DELUXE BULL BARS & WINCH BARS

Including Air Bag Equipped Models

<u>Year</u>	<u>Type</u>	<u>Features</u>	<u>Winches</u>	<u>Part No.</u>
2001-06	Nudge Bar	Driving light provision http://arbusa.com/ford.php	N/A	3140020

IPF LIGHTS & LIGHTING ACCESSORIES

<u>Year</u>	<u>Recommended Lighting</u>
2001-06	800XSD, 900XS, 900HID, 960S/R, 868CS, 968CS, J-01

SAFARI SNORKELS

<u>Year</u>	<u>Recommended Snorkel</u>
N/A	N/A

OLD MAN EMU SUSPENSION PRODUCTS

<u>Model</u>	<u>Location</u>	<u>Description</u>	<u>Type</u>	<u>Lift</u>	<u>Quantity</u>	<u>Part No.</u>
2001-06	Front	Standard Load	Spring	30mm	2	OME904
			Strut cartridge			2
	Rear	Standard Load	Spring	30mm	2	OME905
			Shock			2

¹ The interior trim needs to be removed to fit rear shock absorbers. Care must be taken and 3 hours allowed for removal.