

PATHFINDER (USA MODELS ONLY)

ARB DELUXE BULL BARS & WINCH BARS				
YEAR	MODEL	FEATURES	WINCHES	PART NO.
2008-12	WINCH BAR	AIRBAG APPROVED, OPTIONAL RECESSED FOG LAMP PROVISION ³ , URETHANE BUFFERS, TOW POINTS ² , BLACK	HS9500, XD9000, M8000, M6000	3438290
2005-07	WINCH BAR	AIRBAG APPROVED, OPTIONAL RECESSED FOG LAMP PROVISIONS ³ , URETHANE BUFFERS, TOW POINTS ² , BLACK	HS9500, XD9000, M8000, M6000	3438260
2000-02	SAHARA BAR	AIRBAG APPROVED, RECESSED FOG LAMP PROVISION ¹ , URETHANE BUFFERS, TOW POINTS ² , GREY	HS9500, XD9000, M8000, M6000	3938040

¹ OPTIONAL ARB FOG LAMP KIT PART NO. 3500590. 3500530 REQUIRED WHEN FITTING 3500590 TO MODELS WITHOUT OE FOG LAMPS

² UTILIZES ORIGINAL EQUIPMENT TOW POINTS.

³ OPTIONAL ARB FOG LAMP KIT PART NO. 6821201. 3500440 LOOM REQUIRED WHEN FITTING 6821201 TO MODELS WITHOUT OE FOG LAMPS

* DISCONTINUED BAR

IPF LIGHTING & ACCESSORIES		
YEAR	TYPE	RECOMMENDED LIGHTING
2008-12	3438290	800XSD, 901XSD, 901XSS, 900HIDD, 900HIDS, 868CS, 968CSG
2005-07	3438260	800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG
2000-02	3938020	800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG

SAFARI SNORKEL		
YEAR	RECOMMENDED SNORKEL	PART NO.
1986-97	D21, 2.7L, DIESEL, LEFT SIDE MOUNT	SS700HF

REFER TO WWW.SAFARI4X4.COM.AU FOR DETAILS.

OLD MAN EMU SUSPENSION SYSTEMS						
MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
1996-04 R50 MODELS	FRONT	STOCK/LIGHT LOAD (0-60LBS)	SPRING	.50"	1	2921
		RIGHT SIDE	SHOCK		1	N146S
		LEFT SIDE	SHOCK		1	N145S
	FRONT	MEDIUM LOAD (50-110LBS)	SPRING	.50"	1	2923
		RIGHT SIDE	SHOCK		1	N146S
		LEFT SIDE	SHOCK		1	N145S
	FRONT	HEAVY LOAD (110-220LBS)	SPRING	.50"	1	2928
		RIGHT SIDE	SHOCK		1	N146S
		LEFT SIDE	SHOCK		1	N145S
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	.50"	1	2922
		MEDIUM LOAD (TO 1/1999)	SHOCK		2	*N61
		MEDIUM LOAD TO (FROM 2/1999)	SHOCK		2	*N104
1987-95	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	N/A	N/A	N/A ¹
			SHOCK		2	60031
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	.75"	1	2920
			SHOCK		2	60032
REQUIRED		STEERING DAMPER			1	OMESD35

¹ ADJUST FRONT TORSION BAR FOR ADDITIONAL HEIGHT AFTER INSTALLING REAR SPRINGS. SET RIDE HEIGHT TO 1/3 UPPER BUMP STOP CLEARANCE AND 2/3 LOWER BUMP STOP CLEARANCE.

² IT MAY BE NECESSARY TO SLIGHTLY INCREASE THE CLEARANCE IN THE FRONT WISHBONE TO ALLOW SHOCK ABSORBER TO FIT. DO NOT MODIFY SHOCK ABSORBER.

PATHFINDER (USA MODELS ONLY)

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES						
YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
2005 ON	FRONT	R180A	27.8 (1.09")	27	3.69 & UP	RD180
			27.8 (1.09")	27	3.54 & DN	RD181
1987 ON		R200A	30.4 (1.20")	29	ALL	RD202
1987 ON	REAR	H233B, 31 SPLINE, 6 CYL.	32.4 (1.20")	31	ALL	RD136 ²
		H233B, 33 SPLINE, 6 CYL.	33.3 (1.31")	33	ALL	RD135 ²
1986-97	REAR	C200, 29 SPLINE, 4 CYL.	30.4 (1.20")	29	ALL	RD202 ^{1,2}

¹ ONLY SUITABLE FOR DIFFERENTIALS WITH 12MM CROWN WHEEL BOLTS.

² REFER TO DEALER OR CHECK SPLINE COUNT TO DETERMINE AXLE TYPE.