

4RUNNER

ARB DELUXE BULL BARS & WINCH BARS				
YEAR	MODEL	FEATURES	WINCHES	PART NO.
2010-11	WINCH BAR	AIRBAG APPROVED, INDICATORS, RECESSED FOG LAMPS ²	9.5XP, HS9500, XD9000	3421520
2006-09	WINCH BAR	AIRBAG APPROVED, INDICATORS, RECESSED FOG LAMPS ²	9.5XP, HS9500, XD9000,	3421510
2003-05	WINCH BAR	AIRBAG APPROVED, INDICATORS, RECESSED FOG LAMPS ²	9.5XP, HS9500, XD9000,	3421500
1986-95	WINCH BAR	RECESSED INDICATORS, TOW POINTS, BLACK	XD9000, M8000	3414070 ¹
1984-85	WINCH BAR	RECESSED INDICATORS, TOW POINTS, BLACK	XD9000, M8000	3414090

¹ FITMENT OF BAR TO 4RUNNER MODELS MAY REQUIRE MODIFICATIONS - CONTACT ARB FOR DETAILS.

² OPTIONAL ON THIS MODEL - ARB FOG LAMP KIT PART NO. 6821201. ARB FOG LAMP HARNESS PART NO. 3500440 REQUIRED WHEN FITTING 6821201 TO MODELS WITHOUT OE FOG LAMPS

IPF LIGHTING & ACCESSORIES	
YEAR	RECOMMENDED LIGHTING
ALL	800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG 920H - 7" ROUND H4 HEADLAMP CONVERSION LENS (H4 BULBS, NOT INCLUDED) ¹ 820H - RECTANGULAR H4 HEADLAMP CONVERSION LENS (H4 BULBS NOT INCLUDED) ¹

¹ IPF M002 HEADLIGHT UPGRADE HARNESS RECOMMENDED WHEN INSTALLING HIGH PERFORMANCE H4 BULBS

SAFARI SNORKEL		
YEAR	RECOMMENDED SNORKEL	PART NO.
1989-94	3.0L, V6 SNORKEL - NEEDS MODIFICATIONS	SS130HF
1984-88	2.0L/2.2L SNORKEL - NEEDS MODIFICATIONS	SS65HF

OLD MAN EMU SUSPENSION SYSTEMS							
MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
2010-CURRENT	FRONT	LIGHT LOAD - STOCK WEIGHT - NO BAR OR WINCH	SPRING	3"	1	2884 ¹	
		NITROCHARGER SPORT	STRUT		2	90010 ²	
		MEDIUM LOAD - WITH BAR OR WINCH ONLY (70-180LBS)	SPRING	3"	1	2885 ¹	
		NITROCHARGER SPORT	STRUT		2	90010 ²	
		HEAVY LOAD - WITH BAR AND WINCH (230LBS+)	SPRING	3"	1	2887 ¹	
			NITROCHARGER SPORT	STRUT		2	90010 ²
	OPTIONAL		FRONT TRIM SPACER 5MM				OME95PF5 ¹
	REAR	MEDIUM LOAD	SPRING	3"	1	2889	
		NITROCHARGER SPORT	SHOCK		2	60080 ³	
		HEAVY LOAD (440LBS CONSTANT LOAD)	SPRING	3"	1	2898	
NITROCHARGER SPORT		SHOCK		2	60081/60080 ³		
HEAVY LOAD (880LBS CONSTANT LOAD)		SPRING	3"	1	2899		
		NITROCHARGER SPORT	SHOCK		2	60081 ³	
OPTIONAL		REAR STONE GUARD KIT				OME661	

¹ VEHICLES WITH KDSS, MUST HAVE 1 X OME95PF5 SPACER INSTALLED ON THE DRIVER'S SIDE TO MAINTAIN CORRECT TRIM.

² NO TOP MOUNTING BUSHINGS ARE SUPPLIED. RE-USE OE BUSHINGS.

³ OME661 LOWER SHOCK MOUNT STONE GUARD IS RECOMMENDED FOR REAR SHOCKS TO PROTECT AGAINST STONE CHIP DAMAGE.

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
2003-09 MODELS	FRONT	LIGHT LOAD - STOCK WEIGHT - NO BAR OR WINCH	SPRING	1.0"	1	2884 ¹	
		NITROCHARGER SPORT	STRUT		2	90000	
		NITROCHARGER	STRUT		2	N140S	
		MEDIUM LOAD - WITH BAR OR WINCH ONLY (70-180LBS)	SPRING	2.0"	1	2885 ¹	
		NITROCHARGER SPORT	STRUT		2	90000	
		NITROCHARGER	STRUT		2	N140S	
		HEAVY LOAD - WITH BAR AND WINCH (230LBS+)	SPRING	2.5"	1	2886 ¹	
		NITROCHARGER SPORT	STRUT		2	90000	
	REAR	MEDIUM LOAD	SPRING	2.0"	1	2895	
		NITROCHARGER SPORT	SHOCK		2	60004	
		NITROCHARGER	STRUT		2	N141	
		HEAVY LOAD (330LBS TO GVW)	SPRING	2.0"	1	2896	
		NITROCHARGER SPORT	SHOCK		2	*60005/60004	
		NITROCHARGER	SHOCK		2	N142	
		HEAVY CONSTANT LOAD (660LBS TO GVW)	SPRING	2.0"	1	2897	
		NITROCHARGER SPORT	SHOCK		2	60005	
		NITROCHARGER	SHOCK		2	N142	
		OPTIONAL	FRONT TRIM SPACER 5MM				OME95PF5

¹ IMPORTANT: OME FRONT COILS CAN ONLY BE INSTALLED WITH OME NITROCHARGER STRUT AND COIL SEATS.

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
1996-02 MOD- ELS	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	1.25"	1	2880	
		NITROCHARGER SPORT	SHOCK		2	90004	
		HEAVY LOAD (110-240LBS)	SPRING	1.25"	1	2881	
		NITROCHARGER SPORT	SHOCK		2	90004	
	REAR	MEDIUM LOAD	SPRING	2.0"	1	2906	
		NITROCHARGER SPORT	SHOCK		2	60028	
		NITROCHARGER	SHOCK		2	*N86/N86C	
		HEAVY LOAD (330LBS TO GVW)	SPRING	2.5"	1	2890	
		NITROCHARGER SPORT	SHOCK		2	60027	
		NITROCHARGER	SHOCK		2	N86	
		HEAVY CONSTANT LOAD (660LBS TO GVW)	SPRING	3.0"	1	2891	
		NITROCHARGER SPORT	SHOCK		2	60027	
	OPTIONAL	FRONT TRIM PACKER 5MM					OME95PF5
		REAR TRIM PACKER 5MM					OME80PF05
		REAR TRIM PACKER 10MM					OME80PF10

4RUNNER

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
IFS REAR LEAF SPRING PRE 1990 & IFS REAR COILS SPRING 1990-95	FRONT	STOCK/LIGHT LOAD	TORSION	N/A	1	303003 ¹
		NITROCHARGER	SHOCK		2	N98
IFS REAR COIL SPRING MODELS 1990-95	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	1.5"	1	2900
		NITROCHARGER	SHOCK		2	N72F
		HEAVY LOAD (330LBS CONSTANT LOAD)	SPRING	1.5"	1	2901
		NITROCHARGER	SHOCK		2	N72F
IFS REAR LEAF SPRING MODELS PRE 1990	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	2.0"	2	CS009R ³
		NITROCHARGER	SHOCK		2	*N85/N94
		HEAVY CONSTANT (440LBS TO GVW)	SPRING	2.25"	2	CS010R ³
		NITROCHARGER	SHOCK		2	N85
REQ'D FOR INSTALLATION (LEAF SPRING- MODELS ONLY)		REAR LEAF SPRING BUSHING KIT			2	OMESB6
		U BOLTS			4	OMEU53 ²
		STEERING DAMPER			1	OMESD33
		BUSHING SLEEVE			2	181469
	OPTIONAL	GREASABLE SHACKLE KIT			1	OMEGS3
		REAR EXTRA LEAF				D5XL

¹ ADJUST FRONT TORSION BAR FOR ADDITIONAL HEIGHT AFTER INSTALLING REAR SPRINGS. SET RIDE HEIGHT TO 1/3 UPPER BUMP STOP CLEARANCE AND 2/3 LOWER BUMP STOP CLEARANCE.

² INSTALL OE CASTER WEDGES FROM OE SPRING PACK ONTO OME SPRINGS. ENSURE WEDGES ARE FITTED AS PER ORIGINAL POSITION.

³ COMPARE ORIGINAL SPRING PACK HEIGHT TO OME SPRING PACK TO DETERMINE WHETHER OMEU53 OR OMEU53B U BOLTS ARE REQUIRED.

⁴ EXTRA LEAF CAN BE FITTED FOR HEAVIER CONSTANT LOAD CARRYING ABILITY.

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
ALL LEAF SPRINGS 1984-85	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	2.0"	2	CS008FA/B
			SHOCK	2.0"	2	N84
		HEAVY LOAD (110-240LBS)	SPRING	2.0"	2	CS009FA/B
			SHOCK	2.0"	2	*N93/N84
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	2.0"	2	CS009R ⁷
		POST '84	SHOCK	2.0"	2	*N85/N94 ⁵
		PRE '84	SHOCK	2.0"	2	*N89/N95 ⁵
		HEAVY CONSTANT (550LBS TO GVW)	SPRING	2.25"	2	CS010R ⁷
	POST '84	SHOCK	2.25"	2	N85 ⁵	
	PRE '84	SHOCK	2.25"	2	N89 ⁵	

¹ A/A SPRING FITMENT MAY BE NEEDED ON SOME VEHICLES FOR TRIMMING PURPOSES.

² CAN BE USED ON FRONT APPLICATION ONLY

³ SHOCK SELECTION N89/N95 FOR MEDIUM AND N89 FOR HEAVY APPLICATIONS APPLIES TO VEHICLES UP TO 1984 DUE TO A 16MM EYE AND SHORTER OPEN AND CLOSED LENGTHS. POST 1984 VEHICLES WITH 19MM EYE USE N85/N94 FOR MEDIUM APPLICATIONS AND N85 FOR HEAVY APPLICATIONS.

⁴ OMEU52 IS REQUIRED WHEN FITTING CS009FA/B OR CS008FA/B SPRINGS BECAUSE ORIGINAL U BOLT WILL FOUL DRAG LINK ON FULL DROOP.

⁵ REFER TO OME FITTING MANUAL.

⁶ PICK UP MODELS MAY REQUIRE AN FK03 (SADDLE CORRECTION PLATES) IF THE SPRING SEATS ARE DISTORTED. FK10 MUST BE FITTED TO ALL MODELS USED CONTINUALLY OFF ROAD. REFER TO OME FITTING MANUAL.

⁷ EXTRA LEAF CAN BE FITTED FOR HEAVIER CONSTANT LOAD CARRYING ABILITY.

A TRIM SPACER MAY BE REQUIRED TO TRIM VEHICLE. ONLY TO BE USED ON REAR SPRINGS. IMPORTANT: INSTALL LEAF SPRINGS WITH MILITARY WRAP AT THE FIXED END.

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
ALL LEAF SPRINGS 1984-85	REQ'D FOR INSTALLATION	FRONT SPRING BUSHING KIT			2	OMESB5
		REAR SPRING BUSHING KIT			2	OMESB6
		FRONT U BOLTS			1	OMEU52 ⁴
		BUSHING SLEEVE			2	181469
		REAR U BOLTS			4	OMEU53
		REAR ANTI INVERSION KIT (POST '84)			1	FK13 ⁵
		STEERING DAMPER			1	OMESD21
OPTIONAL		FRONT GREASABLE SHACKLE KIT			1	OMEGS4
		REAR GREASABLE SHACKLE KIT			1	OMEGS3
		GREASABLE PIN KIT			1	OMEGP3 ²
		REAR ANTI INVERSION KIT (PRE '84)			1	FK09 ⁵
		FRONT FITTING KIT			1	FK03/FK10 ⁵
		FRONT EXTRA LEAF				D17XL ⁶
		REAR EXTRA LEAF				D5XL ⁶
		REAR TRIM SPACER				TP04 ⁷

¹ A/A SPRING FITMENT MAY BE NEEDED ON SOME VEHICLES FOR TRIMMING PURPOSES.

² CAN BE USED ON FRONT APPLICATION ONLY

³ SHOCK SELECTION N89/N95 FOR MEDIUM AND N89 FOR HEAVY APPLICATIONS APPLIES TO VEHICLES UP TO 1984 DUE TO A 16MM EYE AND SHORTER OPEN AND CLOSED LENGTHS. POST 1984 VEHICLES WITH 19MM EYE USE N85/N94 FOR MEDIUM APPLICATIONS AND N85 FOR HEAVY APPLICATIONS.

⁴ OMEU52 IS REQUIRED WHEN FITTING CS009FA/B OR CS008FA/B SPRINGS BECAUSE ORIGINAL U BOLT WILL FOUL DRAG LINK ON FULL DROOP.

⁵ REFER TO OME FITTING MANUAL.

⁶ PICK UP MODELS MAY REQUIRE AN FK03 (SADDLE CORRECTION PLATES) IF THE SPRING SEATS ARE DISTORTED. FK10 MUST BE FITTED TO ALL MODELS USED CONTINUALLY OFF ROAD. REFER TO OME FITTING MANUAL.

⁷ EXTRA LEAF CAN BE FITTED FOR HEAVIER CONSTANT LOAD CARRYING ABILITY.

A TRIM SPACER MAY BE REQUIRED TO TRIM VEHICLE. ONLY TO BE USED ON REAR SPRINGS. IMPORTANT: INSTALL LEAF SPRINGS WITH MILITARY WRAP AT THE FIXED END.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
2003-11	FRONT	8" DIA. RG, IFS, 53MM BEARING ID	33 (1.31")	30	3.91 & UP	RD111 ³
2003-11		8" DIA. RG, IFS, 53MM BEARING ID	33 (1.31")	30	3.73 & DN	RD121 ³
TO 2002		8" DIA. RG, 10 BOLT, LIVE AXLE	33 (1.31")	30	ALL	RD132
TO 2002		7.5 DIA. RG 10 BOLT, IFS	28 (1.1")	27	ALL	RD90
1984-88	REAR	4 CYLINDER, 45MM CARRIER BEARING	33 (1.31")	30	ALL	RD132 ¹
1988-09		V6, 4WD, 50MM CARRIER BEARING	33 (1.31")	30	ALL	RD132 ²
1988-09		V6,2WD, 45MM CARRIER BEARING	33 (1.31")	30	ALL	RD132 ^{1,2}
2010-ON		8.25" DIA RG, 12-BOLT (SHIMMED)	33 (1.31")	30	ALL	RD193

¹ LATE MODEL 50.00MM (1.969") ID BEARINGS MUST BE USED WITH THIS SPECIFIC APPLICATION. (ARB PART No. 160116)

² SUITS OPEN DIFFERENTIAL CARRIERS ONLY

³ AFTERMARKET GEARS MAY REQUIRE RD111 - CHECK WITH GEAR MANUFACTURER

ARB ROOF RACKS

YEAR	DESCRIPTION	PART NO.
2003-CURRENT	70X44" STEEL RACK WITH MESH FLOOR	3813010M
	70X44" STEEL RACK WITHOUT MESH FLOOR	3813010
	70X44" ALLOY RACK WITH MESH FLOOR	4913010M
	70X49" TOURING RACK TO SUIT ARB ROOF TOP TENT	3813200
2003-09	FITTING KIT FOR 70X44" RACKS	3722010
2010-CURRENT	FITTING KIT FOR 70X44" RACKS	3722020
OPTIONAL	HI-LIFT JACK AND SHOVEL HOLDER FOR ARB ROOF RACK	K6202
	DOUBLE JERRY CAN HOLDER (BOLTS TO ROOF RACK)	3500390*

* WORKS WITH MOST STEEL JERRY CANS. WILL NOT WORK WITH PLASTIC JERRY CANS

