

HILUX 1979-2012

ARB DELUXE BULL BARS & WINCH BARS				
YEAR	MODEL	FEATURES	WINCHES	PART NO.
1986-94 US PICKUPS	WINCH BAR	RECESSED INDICATORS TOW POINTS, BLACK	XD9000, M8000	3414070 ¹
1997-01 HILUX/TIGER	WINCH BAR	AIRBAG APPROVED, RECESSED INDICATORS, TOW POINTS, FOR MODELS WITH FLARES, BLACK	XD9000, M8000, 9.5XP	3414160
2002-05 HILUX/TIGER	WINCH BAR	AIRBAG APPROVED, RECESSED INDICATORS, TOW POINTS, FOR MODELS WITHOUT FLARES, BLACK	XD9000, M8000, 9.5XP	3414210
2002-05 HILUX/TIGER	WINCH BAR	AIRBAG APPROVED, RECESSED INDICATORS, TOW POINTS, FOR MODELS WITH FLARES, BLACK	XD9000, M8000, 9.5XP	3414220
2005-12 HILUX/VIGO	WINCH BAR	AIRBAG APPROVED, RECESSED INDICATORS, TOW POINTS, FOR MODELS WITHOUT FLARES, BLACK	XD9000, M8000, 9.5XP	3414300
2005-12 HILUX/VIGO	WINCH BAR	AIRBAG APPROVED, RECESSED INDICATORS, TOW POINTS, FOR MODELS WITH FLARES, BLACK	XD9000, M8000, 9.5XP	3414310

¹ FITMENT OF BAR TO 1986-88 MODELS REQUIRE MODIFICATIONS.

IPF LIGHTING & ACCESSORIES		
YEAR	MODEL	RECOMMENDED LIGHTING
ALL	ALL	800XSD, 868CS, 968CSG, 920H ¹ - 7" ROUND H4 HEADLAMP CONVERSION LENS, 820H ¹ - RECTANGULAR H4 HEADLAMP CONVERSION LENS (H4 BULBS NOT INCLUDED WITH LENSES)

¹ IPF M002 HEADLIGHT UPGRADE HARNESS RECOMMENDED WHEN INSTALLING HIGH PERFORMANCE H4 BULBS

SAFARI SNORKEL		
YEAR	RECOMMENDED SNORKEL	PART NO.
2005-11	1GR-FE 4.0L V6, PETROL	SS125HF
2005-11	1KD-FTV, 3.0L I-4, DIESEL	SS120HF
1997-05	3.0L, I4, 1KZ-TE, DIESEL	SS143HF
1997-05	5L-E, 3.0L I-4, DIESEL	SS146HF
1997-05	5L, 3.0L I-4, DIESEL	SS145HF
1997-05	3L, 2.8L I-4, DIESEL	SS135HFD
1997-05	5VZ-FE, 3.4L-V6, PETROL	SS136HF
1997-05	3VZ-E, 3.0L-V6, PETROL	SS136HF
1997-05	3RZ-FE, 2.7L-I4, PETROL	SS135HF
1989-94	3.0L, V6 SNORKEL - NEEDS MODIFICATIONS	SS130HF
1984-88	2.0L/2.2L SNORKEL - DESIGNED FOR 22R ENGINES. IF FITTING TO 22RE, MODIFICATIONS ARE REQ'D.	SS65HF

REFER TO WWW.SAFARI4X4.COM.AU FOR DETAILS.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES						
YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
ALL	FRONT	4WD - 10 BOLT, LIVE AXLE	33 (1.31")	30	ALL	RD132 ²
		4WD - 7.5 DIA. RG 10 BOLT, IFS	28 (1.1")	27	ALL	RD90 ¹
	REAR	4 CYL, 8" DIA. RG	33 (1.31")	30	ALL	RD132 ^{2,3}
		V6, 1 TON, 8" DIA. RG	33 (1.31")	30	ALL	RD132 ²

¹ DOES NOT FIT SOME 1986-1995 MANUAL HUB MODELS WITH LARGER 33MM (1.30") DIA. 27 SPLINE AXLE SHAFTS.

² RD132 SUPERSEDES RD23 MARCH 2007

³ LATE MODEL 50.00MM [1.969"] ID CARRIER BEARINGS MUST BE USED. (ARB PART No. 160116)

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
2005-12 HILUX/ VIGO	FRONT	LIGHT/MEDIUM LOAD (0-110LBS)	SPRING	1.0"	1	2883	
		NITROCHARGER SPORT	SHOCK		2	90002	
		HEAVY LOAD (110-220LBS)	SPRING	1.0"	1	2884	
		NITROCHARGER SPORT	SHOCK		2	90002	
	REAR	LOW LIFT LIGHT LOAD	SPRING	0.5"	2	CS043R-15	
		NITROCHARGER SPORT	SHOCK		2	60006	
		LIGHT LOAD	SPRING	1.75"	2	CS043R	
		NITROCHARGER SPORT	SHOCK		2	60006	
		MEDIUM LOAD	SPRING	1.75"	2	CS044R	
		NITROCHARGER SPORT	SHOCK		2	60006	
		HEAVY CONSTANT LOAD (880LBS TO GVW)	SPRING	1.75"	2	CS045R	
		NITROCHARGER SPORT	SHOCK		2	60007	
		INSTALLATION	SPRING BUSHING KIT			2	OMESB98
			U BOLTS			4	OMEU53
GREASABLE SHACKLE KIT				1	OMEGS14		
BRAKE PROPORTIONING VALVE RELOCATION KIT				1	FK59		
FRONT TRIM PACKER (OPTIONAL)				EACH	OME95PF5		
PICKUPS WITH IFS & REAR LEAFS 1989-94	FRONT	STOCK/LIGHT LOAD (0-90LBS)	TORSION		1	303003 ⁸	
			SHOCK		2	60072	
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	1.75"	2	CS019R	
			SHOCK		2	*60065/60062	
		HEAVY CONSTANT (440LBS TO GVW)	SPRING	2.25"	2	CS020R	
			SHOCK		2	*60065/60062	
	INSTALLATION	REAR LEAF SPRING BUSHING KIT			2	OMESB43	
		REAR U BOLTS			4	OMEU53B	
		BUSHING SLEEVE			2	181469	
		STEERING DAMPER			1	OMESD33	
OPTIONAL	REAR EXTRA LEAF			2	D6XL ⁶		
1986-88	FRONT	STOCK/LIGHT LOAD (0-90LBS)	TORSION		1	303003 ¹	
			SHOCK		2	60072	
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	2.0"	2	CS009R ²	
			SHOCK		2	*60065/60062	
		HEAVY CONSTANT (440LBS TO GVW)	SPRING	2.25"	2	CS010R ²	
			SHOCK		2	60065	

CONTINUED ON THE NEXT PAGE

HILUX 1979-2012

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
1986-88	INSTALLATION	SPRING BUSHING KIT			2	OMESB6
		U BOLTS			4	OMEU53
		STEERING DAMPER			1	OMESD33
		REAR EXTRA LEAF				D5XL ³

¹ ADJUST FRONT TORSION BAR FOR ADDITIONAL HEIGHT AFTER INSTALLING REAR LEAF SPRINGS. SET RIDE HEIGHT TO 1/3 UPPER BUMP STOP CLEARANCE AND 2/3 LOWER BUMP STOP CLEARANCE.

² INSTALL OE CASTER WEDGES FROM OE SPRING BACK ONTO OME SPRINGS. ENSURE WEDGES ARE FITTED AS PER ORIGINAL POSITIONS

³ EXTRA LEAF CAN BE FITTED FOR HEAVIER CONSTANT LOAD CARRYING ABILITY

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
ALL LEAF SPRING PICK- UPS 1979-85	FRONT	STOCK/LIGHT LOAD (0-110LBS)	SPRING	2.0"	2	CS008FA/B ¹
			SHOCK	2.0"	2	60061
		HEAVY LOAD (110-240LBS)	SPRING	2.0"	2	CS009FA/B ¹
			SHOCK	2.0"	2	60061
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	2.0"	2	CS009R ⁷
		POST '84	SHOCK	2.0"	2	*60065/60062 ³
		PRE '84	SHOCK	2.0"	2	*60064/60032 ³
		HEAVY CONSTANT (550LBS TO GVW)	SPRING	2.25"	2	CS010R ⁷
		POST '84	SHOCK	2.25"	2	60065 ⁵
		PRE '84	SHOCK	2.25"	2	60064 ⁵
INSTALLATION	FRONT SPRING BUSHING KIT				2	OMESB5
	REAR SPRING BUSHING KIT				2	OMESB6
	FRONT U BOLTS				2	OMEU52 ⁴
	REAR U BOLTS				4	OMEU53
	REAR ANTI INVERSION KIT (POST '84)				1	FK13 ^{5,9}
	REAR ANTI INVERSION KIT (PRE '84)				1	FK09 ⁹
	STEERING DAMPER				1	OMESD21
OPTIONAL	FRONT GREASABLE SHACKLE KIT				1	OMEGS4
	REAR GREASABLE SHACKLE KIT				1	OMEGS3
	GREASABLE PIN KIT				NOTE ²	OMEGP3 ²
	FRONT FITTING KIT				1	FK03/FK10 ⁵
	FRONT EXTRA LEAF				EACH	D17XL ⁷
	REAR EXTRA LEAF				EACH	D5XL ⁷
	REAR TRIM SPACER				EACH	TP04 ⁸

¹ A/A SPRING FITMENT MAY BE NEEDED ON SOME VEHICLES FOR TRIMMING PURPOSES.

² 1979-83 MODELS CAN USE FRONT AND REAR. 1984-85 CAN USE ON FRONT ONLY

³ SHOCK SELECTION 60064/60032 FOR MEDIUM AND 60064 FOR HEAVY APPLICATIONS APPLIES TO VEHICLES UP TO 1984 DUE TO A 16MM EYE AND SHORTER OPEN AND CLOSED LENGTHS. POST 1984 VEHICLES WITH 19MM EYE USE 60065/60062 FOR MEDIUM APPLICATIONS AND 60065 FOR HEAVY APPLICATIONS.

⁴ OMEU52 IS REQUIRED BECAUSE ORIGINAL U BOLT WILL FOUL DRAG LINK ON FULL DROOP.

⁵ PICK UP MODELS MAY REQUIRE AND FK03 (SADDLE CORRECTION PLATES) IF THE SPRING SEATS ARE DISTORTED. FK10 MUST BE FITTED TO ALL MODELS USED CONTINUALLY OFF ROAD.

⁷ EXTRA LEAF CAN BE FITTED FOR HEAVIER CONSTANT LOAD CARRYING ABILITY.

⁸ A TRIM SPACER MAY BE REQUIRED TO TRIM VEHICLE. ONLY TO BE USED ON REAR SPRINGS. IMPORTANT: INSTALL LEAF SPRINGS WITH MILITARY WRAP AT THE FIXED END.

⁹ FK09 FITS ALL PRE 1984 MODELS. FK13 IS A REPLACEMENT SIDE PLATE INCORPORATING SPRING ANTI INVERSION FEATURE, SUITABLE FOR ALL 1985 MODELS

* FIRMER SHOCKS