

LAND CRUISER 100 SERIES(IFS MODELS)/LEXUS LX470

ARB DELUXE BULL BARS & WINCH BARS				
YEAR	MODEL	FEATURES	WINCHES	PART NO.
2003-07 IFS MODELS	SAHARA BAR	AIRBAG APPROVED, RECESSED INDICATORS, URETHANE BUFFERS, TOW POINTS ³ , RECESSED FOG LAMPS ⁵ , GREY	M12000, XD9000, M8000	3913160 ^{6,7}
2002-07 IFS MODELS	COMBO BAR (LC100 ONLY)	AIRBAG APPROVED, RECESSED INDICATORS, URETHANE BUFFERS, TOW POINTS ³ , RECESSED FOG LAMPS ⁵ , BLACK	M12000, XD9000, M8000	3413190 ⁴
1998-02 IFS MODELS	SAHARA BAR	AIRBAG APPROVED, RECESSED INDICATORS, URETHANE BUFFERS, TOW POINTS ³ , RECESSED FOG LAMPS ⁵ , GREY	XD9000, M8000	3913140 ^{8,9}
1998-02 IFS MODELS	COMBO BAR (LC100 ONLY)	AIRBAG APPROVED, RECESSED INDICATORS, TOW POINTS ³ , SPLIT PAN, BLACK	M12000, HS9500, XD9000 ² , M8000 ²	3413050 ⁴

² FITMENT OF WARN XD9000 & M8000 WINCH REQUIRES SPECIAL SPACER KIT - ARB PART NO. 3500050.

³ UTILIZES ORIGINAL EQUIPMENT TOW POINTS.

⁴ THE LEXUS LX470 WILL ONLY ACCEPT SAHARA BAR MODELS.

⁵ OPTIONAL ARB FOG LAMP KIT PART NO. 6821201. 3500440 LOOM REQUIRED WHEN FITTING 6821201 TO MODELS WITHOUT OE FOG LAMPS

⁶ OPTIONAL CHROME CENTER TUBE REQUIRES ADDITIONAL PART #'S 5100160 AND 5100060 TO COMPLETE INSTALLATION

⁷ IF THE OPTIONAL CHROME CENTER TUBE IS NOT BEING INSTALLED, ADDITIONAL PART # 5100170 REQUIRED TO COMPLETE INSTALLATION.

⁸ OPTIONAL CHROME CENTER TUBE REQUIRES ADDITIONAL PART #'S 5100160 AND 5100050 TO COMPLETE INSTALLATION

⁹ IF THE OPTIONAL CHROME CENTER TUBE IS NOT BEING INSTALLED, ADDITIONAL PART # 5100170 REQUIRED TO COMPLETE INSTALLATION.

IPF LIGHTING & ACCESSORIES

YEAR	RECOMMENDED LIGHTING
1998-07	800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG

SAFARI SNORKEL

YEAR	RECOMMENDED SNORKEL	PART NO.
4/1998-07	ALL MODELS	SS86HF ¹

¹ANTENNA MODIFICATIONS MAY BE REQUIRED FOR FITMENT ON LEFT HAND DRIVE VEHICLES

ARB SLIDERS/SIDE RAILS/STEPS

YEAR	MODEL	DESCRIPTION	PART NO.
1998-02	IFS MODELS TO 10/02	TWO-PIECE SIDE PROTECTION RAILS AND STEPS (BOTH PARTS REQUIRED, AS WELL AS ARB COMBO BAR BUMPER FOR MOUNTING), BLACK	4413250, 4413260
2002-07	IFS MODELS 11/02 ON	TWO-PIECE SIDE PROTECTION RAILS AND STEPS (BOTH PARTS REQUIRED, AS WELL AS ARB COMBO BAR BUMPER FOR MOUNTING), BLACK. (WILL NOT FIT VEHICLES EQUIPPED WITH HYDRAULIC RIDE CONTROL SYSTEMS)	4413270, 4413260

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
1998-07	FRONT (IFS)	8" DIA. RG, IFS, 50MM BEARING ID	33 (1.31")	30	ALL	RD131
	REAR	ALL MODELS	34.8 (1.37")	32	ALL	RD152

ARB ROOF RACKS

YEAR	DESCRIPTION	PART NO.
100 SERIES	44X44" RACK WITH MESH FLOOR	3813020M
	44X44" RACK WITHOUT MESH FLOOR	3813020
	ROOF RACK FIT KIT FOR 44X44" RACK LC100 SERIES	3713020
	WIND DEFLECTOR FOR 44" WIDE ROOF RACK	3700320

¹ CONTACT ARB FOR INFORMATION REGARDING OE VEHICLE PRODUCTION VARIATIONS WHICH MAY EFFECT PROPER RACK FITMENT

THULE ROOF RACK SYSTEMS TO SUIT ARB ROOF TOP TENT

YEAR	MODEL	DESCRIPTION	PART NO.
1998-07	LC100	THULE ROOF RACK SYSTEM TO SUIT ARB ROOFTOP TENT	T45058 ¹

¹ REQUIRES OE RACK TO COMPLETE INSTALLATION

TOYOTA/LEXUS

LAND CRUISER 100 SERIES (IFS MODELS)/LX470

ARB MODULAR REAR BUMPERS WITH SWING-AWAY TIRE AND/OR JERRY CAN HOLDERS			
YEAR	MODEL	DESCRIPTION	PART NO.
1998-07	LC100	DELUXE REAR BAR, BLACK POWDER COAT	5613210 ¹
		LHS BLANK COVER PANEL, BLACK	5700231 ²
		RHS BLANK COVER PANEL, BLACK	5700232 ²
		LHS TIRE CARRIER, BLACK	5700211 ²
		RHS TIRE CARRIER, BLACK	5700212 ²
		LHS JERRY CAN HOLDER, BLACK	5700221 ²
		RHS JERRY CAN HOLDER, BLACK	5700222 ²
	OPTIONAL	LHS CAMP LIGHT	5700041
		RHS CAMP LIGHT	5700042
		ANTENNA MOUNT	5700050
		HILIFT MOUNT FOR WHEEL CARRIER ONLY	5700060
		REVERSING LIGHT KIT	5700070

- ¹ A LEFT OR RIGHT HAND SIDE COVER PANEL MUST BE USED FOR INSTALLATION IF TIRE CARRIER OR JERRY CAN HOLDER IS NOT PURCHASED.
² CUSTOMER CAN USE A COMBINATION OF BLANKS, TIRE CARRIERS, OR JERRY CAN HOLDERS FOR A COMPLETE INSTALLATION. A MINIMUM OF 3 SEPARATE PART NUMBERS WILL BE REQUIRED FOR THIS BAR TO MOUNT TO THE VEHICLE.

OLD MAN EMU SUSPENSION SYSTEMS						
MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
1998-07	FRONT	STOCK/LIGHT LOAD	TORSION	N/A	1	303001/2 ^{1,5}
		NITROCHARGER SPORT	SHOCK		2	*60001/60000
		NITROCHARGER	SHOCK		2	*N133/N100
1998-00	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	1.50"	1	2865
		NITROCHARGER SPORT	SHOCK		2	60002
		NITROCHARGER	SHOCK		2	*N101/N101C
		HEAVY CONSTANT (440LBS TO GVW)	SPRING	1.50"	1	2864
		NITROCHARGER SPORT	SHOCK		2	60003
		NITROCHARGER	SHOCK		2	N101
2000-07	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	2.0"	1	2860 ⁵
		NITROCHARGER SPORT	SHOCK		2	60002
		NITROCHARGER	SHOCK		2	*N101/N101C
		HEAVY CONSTANT (440LBS TO GVW)	SPRING	3.0"	1	2863
		NITROCHARGER SPORT	SHOCK		2	*60003/60002
		NITROCHARGER	SHOCK		2	N101
		OPTIONAL	REAR SHOCK STONE GUARD			
REAR TRIM SPACER 5MM						OME80PR05 ³
REAR TRIM SPACER 10MM						OME80PR10 ³
HEAVY CONSTANT FRONT SHOCK	SHOCK				2	N199 ⁴
HEAVY CONSTANT REAR SHOCK	SHOCK				2	N200 ⁴

- * FIRMER SHOCK
¹ 303001 SUITS V8 MODELS, 303002 SUITS TURBO DIESEL MODELS. ADJUST FRONT TORSION BAR FOR ADDITIONAL HEIGHT AFTER INSTALLING REAR SPRINGS. SET RIDE HEIGHT TO 1/3 UPPER BUMP STOP CLEARANCE AND 2/3 LOWER BUMP STOP CLEARANCE.
² OME660 LOWER SHOCK MOUNT STONE GUARD IS RECOMMENDED FITMENT TO REAR SHOCKS TO PROTECT AGAINST SEVERE STONE PEPPEERING ENCOUNTERED ON LOOSE ROAD SURFACES.
³ TRIM VEHICLE TO A MAXIMUM OF 15MM PER COIL. SPACERS MUST BE INSTALLED ON TOP OF COILS.
⁴ N199 & N200 ARE SPECIFICALLY ENGINEERED TO IMPROVE THE RIDE AND HANDLING OF CUSTOMER VEHICLES THAT ARE HEAVILY LOADED WITH A HIGH CENTER OF GRAVITY CAUSED BY HEAVILY LOADED ROOF RACKS
⁵ WILL NOT WORK WITH AIR BAG SUSPENSION EQUIPPED VEHICLES

