

LAND CRUISER 78/79 SERIES PRE-2007

ARB DELUXE BULL BARS & WINCH BARS

YEAR	MODEL	FEATURES	WINCHES	PART NO.
1985-07	WINCH BAR	RECESSED INDICATORS, TOW POINTS, BLACK	M12000, HS9500, XD9000, M8274	3412130

IPF LIGHTING & ACCESSORIES

YEAR	RECOMMENDED LIGHTING
1985-07	800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG
	920HJKTJ - 7" ROUND H4 HEADLAMP CONVERSION KIT (H4 BULBS, NOT INCLUDED)
	820H - RECTANGULAR H4 HEADLAMP CONVERSION LENS (H4 BULBS NOT INCLUDED)

SAFARI SNORKEL

YEAR	RECOMMENDED SNORKEL	PART NO.
2007-ON	1HZ - 4.2 LITER I6 ENGINE	SS76HFZ
	1GR-FE - 4.0 LITER V6 ENGINE	SS76HFE
1985-07	3F 4.0 LITRE -I6 ENGINE	SS75HF
	1FZ-FE 4.5 LITRE -I6 ENGINE	SS75HFE
	3B 3.4 LITRE -I4 ENGINE	SS73HF
	2H 4.0 LITRE -I6 ENGINE	SS75HF
	1HZ 4.2 LITRE -I6 ENGINE	SS78HFZ

REFER TO WWW.SAFARI4X4.COM.AU FOR DETAILS.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
1998 ON	FRONT	8" DIA. RG, IFS, 1.97 BEARING ID	33 (1.31")	30	ALL	RD92
		LIVE AXLE SUSPENSION	33 (1.31")	30	ALL	RD132
1998 ON	REAR	ALL MODELS	33 (1.31")	30	ALL	RD152

ARB ROOF RACKS

YEAR	DESCRIPTION	PART NO.
79 SERIES	87X49" STEEL RACK WITH MESH FLOOR	3800010M
	87X49" STEEL RACK WITHOUT MESH FLOOR	3800010
	87X49" ALLOY RACK WITH MESH FLOOR	4900010M
	87X49" STEEL TOURING RACK FOR ROOF TOP TENT	3800200
	87X49" FITTING KIT (ALLOY & STEEL)	3700030
	73X49" STEEL RACK WITH MESH FLOOR	3800020M
	73X49" STEEL RACK WITHOUT MESH FLOOR	3800020
	73X49" FITTING KIT	3700030
	43X49" STEEL RACK WITH MESH FLOOR	3800030M
	43X49" FITTING KIT	3700040
78 SERIES	40X49" STEEL RACK WITHOUT MESH FLOOR	3800160
	40X49" FITTING KIT	3700060

LAND CRUISER 78/79 SERIES PRE-2007

OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
ALL GAS & DIESEL, SINGLE CAB & TROOP CARRIER MODELS	FRONT	LIGHT LOAD TO 110LBS	SPRING	1.5"	1	2856
		NITROCHARGER SPORT	SHOCK		2	60008
		NITROCHARGER	SHOCK		2	*N106/N106C
	REQ'D FOR INSTALLATION	STEERING DAMPER			1	OMESD24
		CASTER KIT			1	OMECA77B ¹
	FRONT	HEAVY LOAD 100 TO 240LBS	SPRING	1.5"	1	2859
		NITROCHARGER SPORT	SHOCK		2	60008
		NITROCHARGER	SHOCK		2	N106
	REQ'D FOR INSTALLATION	STEERING DAMPER			1	OMESD24
		CASTER KIT			1	OMECA77B ¹
	FRONT	LOW HEIGHT HEAVY LOAD TO 240LBS	SPRING	1.0"	1	2856
		NITROCHARGER SPORT	SHOCK		2	60008
		NITROCHARGER	SHOCK		2	N106
	REQ'D FOR INSTALLATION	STEERING DAMPER			1	OMESD24
		CASTER KIT			1	OMECA77B ¹
	TROOP CARRIER MODELS	REAR	CONSTANT 440LBS	SPRING	1.75"	2
NITROCHARGER SPORT			SHOCK		2	60010
NITROCHARGER			SHOCK		2	N75E
REQ'D FOR INSTALLATION		SPRING BUSHING			2	OMESB84 ²
		SPRING BUSHING			2	OMESB85 ²
		GREASABLE SHACKLE			1	OMECS10
		GREASABLE PIN KIT			1	OMEGP7
REAR		CONSTANT 880LBS	SPRING	1.75"	2	CS014R
		NITROCHARGER SPORT	SHOCK		2	60011
		NITROCHARGER	SHOCK		2	*N75F/N75E
REQ'D FOR INSTALLATION		SPRING BUSHING			2	OMESB84 ²
		SPRING BUSHING			2	OMESB85 ²
		GREASABLE SHACKLE			1	OMECS10
		GREASABLE PIN KIT			1	OMEGP7
REAR		CONSTANT 1300LBS	SPRING	1.75"	2	CS015R
		NITROCHARGER SPORT	SHOCK		2	60011
	NITROCHARGER	SHOCK		2	N75F	
REQ'D FOR INSTALLATION	SPRING BUSHING			2	OMESB84 ²	
	SPRING BUSHING			2	OMESB85 ²	
	GREASABLE SHACKLE			1	OMECS10	
	GREASABLE KIT			1	OMEGP7	

¹ OMECA77B CASTER KIT WILL INCREASE CASTER BY 2° AFTER RAISING VEHICLE CHECK MANUFACTURER'S SPECIFICATIONS TO DETERMINE IF OMECA77B IS REQUIRED.

² THERE IS A DIFFERENCE BETWEEN THE SHACKLES ON SINGLE CAB MODELS AND TROOP CARRIER MODELS. BE SURE TO SELECT OME BUSH KITS CAREFULLY: OMESB84: USE FOR ALL SINGLE CAB MODELS WHEN ORIGINAL SHACKLES & PINS ARE USED. OMESB85: USE FOR ALL MODELS WHEN INSTALLING OME GREASABLE SHACKLES & PINS. OMESB86: USE FOR TROOP CARRIER MODELS WHEN ORIGINAL SHACKLES & PINS ARE USED.

LAND CRUISER 76/78/79 SERIES 2007 - 2011

ARB DELUXE BULL BARS & WINCH BARS				
YEAR	MODEL	FEATURES	WINCHES	PART NO.
2007-2011	WINCH BARS	AIR BAG COMPATIBLE, FOR MODELS WITHOUT FLARES	XD9000, XP9500, XDC9500	3412400 ⁴
	WINCH BARS	AIR BAG COMPATIBLE, FOR MODELS WITH FLARES, OPTIONAL FOG LAMPS ^{1,2}	XD9000, XP9500, XDC9500	3412410 ^{1,2,4}
	COMMERCIAL	AIR BAG COMPATIBLE, FOR MODELS WITHOUT FLARES	M8000, M12000 ³ , 8000LB HIGH MOUNT MODELS	3412430 ^{3,4}
	COMMERICAL	AIR BAG COMPATIBLE, FOR MODELS WITH FLARES	M8000, M12000 ³ , 8000LB HIGH MOUNT MODELS	3412440 ^{3,4}

¹ OPTIONAL FOG LIGHT KIT PART NO. 6821201²

² FOR VEHICLES WITHOUT FACTORY FITTED FOG LIGHTS, 3500440 LOOM REQUIRED

³ WINCH EXTENSION CABLE KIT PART NO. 3512050 REQUIRED WHEN FITTING AN M12000 WINCH

⁴ OPTIONAL STONE GUARD PART NO. 3512040

IPF LIGHTING & ACCESSORIES	
YEAR	RECOMMENDED LIGHTING
2007-2011	800XSDDCS, 90XSDDCS

SAFARI SNORKEL		
YEAR	RECOMMENDED SNORKEL	PART NO.
2007-ON	1HZ - 4.2 LITER I6	SS76HFZ
	1GR-FE - 4.0 LITER V6	SS76HFE

OLD MAN EMU SUSPENSION SYSTEMS							
MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
76 SERIES V8 DIESEL ENGINES	FRONT	0 - 132LBS	SPRING	2.0"	1	2856	
		NITROCHARGER SPORT	SHOCK		2	60008	
		NITROCHARGER	SHOCK		2	N106	
		132 - 265LBS	SPRING	2.0"	1	2859	
		NITROCHARGER SPORT	SHOCK		2	60008	
		NITROCHARGER	SHOCK		2	N181	
	REQ'D FOR INSTALLATION		STEERING DAMPER			1	OMESD47
			CASTER KIT			1	OMECA77B ¹
			SWAY BAR SPACER KIT			1	FK19 ⁴
	REAR		SPRING: MEDIUM	SPRING	2.0"	2	CS057R
			NITROCHARGER SPORT	SHOCK		2	60010
			NITROCHARGER	SHOCK		2	*N197 / N75E
			CONSTANT 880LBS	SPRING	2.0"	2	CS058R
			NITROCHARGER SPORT	SHOCK		2	60011
		NITROCHARGER	SHOCK		2	N197	
REQ'D FOR INSTALLATION		SPRING BUSH KIT			2	OMESB86 ²	
		SPRING BUSH KIT			2	OMESB85 ²	
		GREASABLE SHACKLE KIT			1	OMEGB19 ³	
		GREASABLE SHACKLE KIT			1	OMEGP7	
		ANTI-INVERSION KIT			1	FK38 ³	
		U BOLTS			4	OMEU59D	

¹ OMECA77B CASTER KIT WILL INCREASE CASTER ANGLE BY 3°. CHECK MANUFACTURER'S SPECIFICATIONS TO DETERMINE IF REQUIRED.

² BE SURE TO SELECT OME BUSH KITS CAREFULLY:

OMESB85: USE FOR ALL MODELS WHEN INSTALLING OME GREASABLE SHACKLES & PINS.

OMESB86: USE WHEN ORIGINAL SHACKLES & PINS ARE USED.

³ TO PREVENT SPRINGS FROM INVERTING IT IS MANDATORY THAT EITHER OMEGB19 GREASABLE SHACKLE KIT OR FK38 ANTI-INVERSION KIT BE INSTALLED.

⁴ SHOULD THE FRONT DRIVE SHAFT CONTACT THE SWAY BAR WHEN THE SUSPENSION IS AT FULL DROOP, USE TO PACK THE SWAY BAR DOWN.



LAND CRUISER 76/78/79 SERIES 2007 - 2011

OLD MAN EMU SUSPENSION SYSTEMS							
MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
78 & 79 SERIES PETROL & DIESEL 6 CYLINDER ENGINES	FRONT	0 - 110LBS	SPRING	1.5"	1	2856 ⁷	
		NITROCHARGER SPORT	SHOCK		2	60008	
		NITROCHARGER	SHOCK		2	*N181/N106	
		110 - 265LBS	SPRING	1.5"	1	2859 ⁷	
		NITROCHARGER SPORT	SHOCK		2	60008	
		NITROCHARGER	SHOCK		2	N181	
	REQ'D TO COMPLETE INSTALLATION	STEERING DAMPER				1	OMESD24 ⁴
		STEERING DAMPER				1	OMESD47 ⁴
		CASTER KIT				1	OMECA77B ¹
		SWAY BAR SPACER KIT				1	FK19 ⁵
		TRIM PACKER				1	OME79PF10
78 & 79 SERIES V8 DIESEL ENGINES	FRONT	0 - 110LBS	SPRING	1.5"	1	2859 ⁷	
		NITROCHARGER SPORT	SHOCK		2	60008	
		NITROCHARGER	SHOCK		2	*N181/N106	
		110 - 265LBS	SPRING	1.5"	1	2853 ⁷	
		NITROCHARGER SPORT	SHOCK		2	60008	
		NITROCHARGER	SHOCK		2	N181	
	REQ'D TO COMPLETE INSTALLATION	STEERING DAMPER				1	OMESD47
		CASTER KIT				1	OMECA77B ¹
		SWAY BAR SPACER KIT				1	FK19 ⁵
		TRIM PACKER				1	OME79PF10
		79 SERIES SINGLE CAB	REAR	CONSTANT 440LBS	SPRING	1.5"	2
NITROCHARGER SPORT	SHOCK				2	60010	
NITROCHARGER	SHOCK				2	*N75F / N75E	
CONSTANT 880LBS	SPRING			1.5"	2	CS014R ⁶	
NITROCHARGER SPORT	SHOCK				2	60011	
NITROCHARGER	SHOCK				2	N197	
CONSTANT 1322LBS	SPRING			1.5"	2	CS015R ⁶	
NITROCHARGER SPORT	SHOCK				2	60011	
NITROCHARGER	SHOCK			2	N197		
REQ'D TO COMPLETE INSTALLATION	SPRING BUSH KIT					2	OMESB101 ²
	SPRING BUSH KIT					2	OMESB84 ²
	SPRING BUSH KIT					2	OMESB85
	GREASABLE SHACKLE KIT					1	OMEGB10
	GREASABLE SHACKLE KIT				1	OMEGB7	
U BOLTS				4	OMEU59B		
SWAY BAR BRACKET KIT				0	NOT REQ'D		

FOOTNOTES FOR 78 & 79 SERIES LAND CRUISER ON THE FOLLOWING PAGE. SEE PAGE #118

LAND CRUISER 76/78/79 SERIES 2007 - 2011

OLD MAN EMU SUSPENSION SYSTEMS							
MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
78 SERIES TROOP CARRIER	REAR	CONSTANT 440LBS	SPRING	1.75"	2	CS013R ⁶	
		NITROCHARGER SPORT	SHOCK		2	60010	
		NITROCHARGER	SHOCK		2	*N75F / N75E	
		CONSTANT 880LBS	SPRING	1.75"	2	CS014R ⁶	
		NITROCHARGER SPORT	SHOCK		2	60011	
		NITROCHARGER	SHOCK		2	N197	
		CONSTANT 1322LBS	SPRING	1.75"	2	CS015R ⁶	
		NITROCHARGER SPORT	SHOCK		2	60011	
		NITROCHARGER	SHOCK		2	N197	
		REQ'D TO COMPLETE INSTALLATION	SPRING BUSH KIT			2	OMESB86 ²
			SPRING BUSH KIT			2	OMESB85 ²
			GREASABLE SHACKLE KIT			1	OMEGB19
			GREASABLE SHACKLE KIT			1	OMEGP7
			U BOLTS			4	OMEU59B
SWAY BAR BRACKET KIT				1	FK34 ³		

* FIRMER SHOCK

¹ OMECA77B CASTER KIT WILL INCREASE CASTER ANGLE BY 3°. CHECK MANUFACTURER'S SPECIFICATIONS TO DETERMINE IF OMECA77B KIT IS REQUIRED.

² THERE IS A DIFFERENCE BETWEEN THE SHACKLES ON SINGLE CAB MODELS AND TROOP CARRIER MODELS.
BE SURE TO SELECT OME BUSH KITS CAREFULLY:

OMESB101: USE ON ORIGINAL SHACKLES & PINS FOR 79 SERIES MODELS FROM 07/2009 ON.

OMESB84: USE ON ORIGINAL SHACKLES & PINS FOR 79 SERIES MODELS TO 06/2009.

OMESB85: USE FOR ALL MODELS WHEN INSTALLING OME GREASABLE SHACKLES & PINS.

OMESB86: USE FOR TROOP CARRIER MODELS WHEN ORIGINAL SHACKLES & PINS ARE USED.

³ FK34 SWAY BAR EXTENSION BRACKET KIT MUST BE INSTALLED TO PREVENT DAMAGE TO SWAY BAR MOUNTS, DUE TO INCREASED SUSPENSION TRAVEL.

⁴ OMESD24 SUITS PRE 2007 MODELS (OPEN LENGTH 651MM).

OMESD47 SUITS 2007ON MODELS (OPEN LENGTH 750MM).

⁵ SHOULD THE FRONT DRIVE SHAFT CONTACT THE SWAY BAR WHEN THE SUSPENSION IS AT FULL DROOP, USE FK19 SPACER KIT TO PACK THE SWAY BAR DOWN.

⁶ INCLUDE TRAY/BED WEIGHT IN CONSTANT LOAD CALCULATION.

⁷ TO MAINTAIN CORRECT REAR TO FRONT RIDE HEIGHT RAKE, NO MORE THAN 40MM OF FRONT LIFT SHOULD BE ACCEPTED.

ARB SLIDERS/SIDE RAILS/STEPS			
YEAR			PART NO.
2007-11	76 SERIES	SIDE RAIL WITH INTEGRATED STEP	4412320
2007-11	78 SERIES	SIDE RAIL WITH INTEGRATED STEP	4412330
2007-11	79 SERIES	SIDE RAIL WITH INTEGRATED STEP	4412300

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES						
YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
2007-11	FRONT	SOLID/LIVE AXLE MODEL	33 (1.31")	30	ALL	RD132
2007-11	REAR	ALL MODELS	34.8 (1.37")	32	ALL	RD152