

## TUNDRA

### ARB DELUXE BULL BARS & WINCH BARS

YEAR	MODEL	FEATURES	WINCHES	PART NO.
1999-06	SAHARA BAR	AIRBAG APPROVED, RECESSED FOG LAMPS <sup>12</sup> , URETHANE BUFFERS, TOW POINTS, SPLIT PAN	M15000, M12000	3915060 <sup>2</sup>
2007-13	WINCH BAR	AIRBAG APPROVED, RECESSED FOG LAMPS <sup>8</sup> , TOW POINTS, SPLIT PAN	M16.5TI, M15000, M12000 <sup>10</sup>	3415010 <sup>3,9,11</sup>
2007-13	SAHARA BAR	OPTIONAL ALLOY CENTER TUBE, AIRBAG APPROVED, RECESSED FOG LAMPS <sup>7</sup> , TOW POINTS, SPLIT PAN	M16.5TI, M15000, M12000 <sup>10</sup>	3915030 <sup>5,6,9</sup>

- <sup>1</sup> USES OPTIONAL IPF PART NUMBER 9381FCK
- <sup>2</sup> DOUBLE CAB 4 DOOR MODELS REQUIRE MODIFICATIONS TO FIT BUMPER - CONTACT ARB FOR DETAILS.
- <sup>3</sup> FRONT SUSPENSION REQUIRED TO ACCOMMODATE THE ADDED WEIGHT OF THE ARB BUMPER
- <sup>4</sup> WILL WORK WITH OE FOG LAMPS, OR OPTIONAL ARB FOG LAMP KIT PART NO. 6821201. 3500440 REQUIRED WHEN FITTING 6821201 TO MODELS WITHOUT OE FOG LAMPS
- <sup>5</sup> OPTIONAL CHROME CENTER TUBE REQUIRES ADDITIONAL PART #'S 5100140 AND 5115030 TO COMPLETE INSTALLATION
- <sup>6</sup> IF THE OPTIONAL CHROME CENTER TUBE IS NOT BEING INSTALLED, ADDITIONAL PART # 5100150 IS REQUIRED TO COMPLETE INSTALLATION
- <sup>7</sup> OPTIONAL ARB FOG LAMP KIT PART NO. 6821201. 3500440 REQUIRED WHEN FITTING 6821201 TO MODELS WITHOUT OE FOG LAMPS
- <sup>8</sup> OE FOG LAMPS OR OPTIONAL IPF FOG LAMP KIT PART NUMBER 9381FCK
- <sup>9</sup> 2010+ MODELS WITH "MILLENNIUM" OR "LIMITED" GRILLS MAY NEED MODIFICATION. PLEASE CONTACT ARB FOR DETAILS (425) 264-1391
- <sup>10</sup> IF FITTING 12000LB WINCH, EXTRA LONG CABLE KIT 3512050 IS REQUIRED
- <sup>11</sup> ROCK WARRIOR EDITION TUNDRA GRILL ASSEMBLIES WILL NOT CLEAR ARB BULLBARS
- <sup>12</sup> OPTIONAL ARB FOG LAMP KIT PART NO. 3500590. 3500530 REQUIRED WHEN FITTING 3500590 TO MODELS WITHOUT OE FOG LAMPS

### IPF LIGHTING & ACCESSORIES

YEAR	MODEL	RECOMMENDED LIGHTING
1999-13	ALL	ARB INTENSITY LED, 800XSD, 901XSD, 901XSS, 900HIDD, 900HIDS, 900DB 968CSG, 968CSB, 900DB

### OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.
2007-17	<b>COMPLETE KITS</b>	4.7L V8 STOCK/LIGHT LOAD (0-150LBS)	KIT	2.5"	1	OMETUN47LKS <sup>4</sup>
		4.7L V8 HEAVY LOAD (200LBS+)	KIT	2.5"	1	OMETUN47HKS <sup>4</sup>
		5.7L V8 STOCK/LIGHT LOAD (0-150LBS)	KIT	2.5"	1	OMETUN57LKS <sup>4</sup>
		5.7L V8 HEAVY LOAD (200LBS+)	KIT	2.5"	1	OMETUN57HKS <sup>4</sup>
	FRONT	STOCK/LIGHT LOAD (0-150LBS)	SPRING	2.50"	1	2612
		NITROCHARGER SPORT	STRUT		2	90018
		HEAVY LOAD 4.7 LITER ENGINE (200LBS+)	SPRING	2.50"	1	2614
		NITROCHARGER SPORT	STRUT		2	90018
		HEAVY LOAD 5.7 LITER ENGINE (200LBS+)	SPRING	2.50"	1	2613
		NITROCHARGER SPORT	STRUT		2	90018
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING	2.50"	2	CS055R <sup>3</sup>
		NITROCHARGER SPORT	SHOCK		2	60100
	REQUIRED	FITTING KIT			1	FK32 <sup>1</sup>
		U BOLTS			4	OMEU53B
	OPTIONAL	SPRING BUSH KITS WHEN USED WITH OMEGS22 SHACKLES			2	OMESB106
		SPRING BUSH KITS WHEN USED WITH FACTORY SHACKLES				SEE NOTE <sup>2</sup>
GREASABLE SHACKLE KIT				1	OMEGS22	
EXTRA LEAF				2	D28XL	

- <sup>\*\*</sup> OME FRONT COILS CAN ONLY BE INSTALLED WITH OME NITROCHARGER STRUTS AND COIL SEATS.
- <sup>1</sup> FK32 FITTING KIT IS A BRAKE LINE AND ABS WIRE BRACKET RELOCATION KIT AND IS A MANDATORY FITMENT.
  - <sup>2</sup> NEW BONDED RUBBER BUSHES ARE SUPPLIED WITH THE LEAF SPRINGS
  - <sup>3</sup> TRD MODELS WITH REAR SWAYBARS MAY REQUIRE LONGER LINKS TO RETAIN SWAYBAR OPERATION.
  - <sup>4</sup> COMPLETE KITS CONTAIN NITROCHARGER SPORT SHOCKS & STRUTS.



### ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
1999-06	FRONT	7.5" DIA. RG, 10 BOLT, IFS	28 (1.1")	27	ALL	RD90
1999-06	REAR	8" DIA. RG, 12 BOLT	33 (1.31")	30	ALL	RD129
2007-17	FRONT	8" IFS, 58MM BEARING	35 (1.38")	34	ALL	RD151
2007-17	REAR	4.7 LITER ENGINE 9.5" DIA. RG	35 (1.37")	32	ALL	RD152
		5.7 LITER ENGINE 10.5" DIA RG				36