

TUNDRA

ARB DELUXE BULL BARS & WINCH BARS				
YEAR	MODEL	FEATURES	WINCHES	PART NO.
1999-06	SAHARA BAR	AIRBAG APPROVED, RECESSED FOG LAMPS ¹² , URETHANE BUFFERS, TOW POINTS, SPLIT PAN	M15000, M12000	3915060 ²
2007-13	WINCH BAR	AIRBAG APPROVED, RECESSED FOG LAMPS ⁸ , TOW POINTS, SPLIT PAN	M16.5TI, M15000, M12000 ¹⁰	3415010 ^{3,9,11}
2007-13	SAHARA BAR	OPTIONAL ALLOY CENTER TUBE, AIRBAG APPROVED, RECESSED FOG LAMPS ⁷ , TOW POINTS, SPLIT PAN	M16.5TI, M15000, M12000 ¹⁰	3915030 ^{5,6,9}
2014-18	SUMMIT BAR	AIRBAG APPROVED, ARB FOG LIGHTS ¹³ RECESSED LED INDICATORS, URETHANE BUFFERS, JACK POINTS, INTEGRIT BLACK	M8000, XD9000, XP9.5, XDC9.5, ZEON 8, 10, ZEON PLAT 10,	3415020K ^{13,14,15,16}

- ¹ USES OPTIONAL IPF PART NUMBER 9381FCK
- ² DOUBLE CAB 4 DOOR MODELS REQUIRE MODIFICATIONS TO FIT BUMPER - CONTACT ARB FOR DETAILS.
- ³ FRONT SUSPENSION REQUIRED TO ACCOMMODATE THE ADDED WEIGHT OF THE ARB BUMPER
- ⁴ WILL WORK WITH OE FOG LAMPS, OR OPTIONAL ARB FOG LAMP KIT PART NO. 6821201. 3500440 REQUIRED WHEN FITTING 6821201 TO MODELS WITHOUT OE FOG LAMPS
- ⁵ OPTIONAL CHROME CENTER TUBE REQUIRES ADDITIONAL PART #'S 5100140 AND 5115030 TO COMPLETE INSTALLATION
- ⁶ IF THE OPTIONAL CHROME CENTER TUBE IS NOT BEING INSTALLED, ADDITIONAL PART # 5100150 IS REQUIRED TO COMPLETE INSTALLATION
- ⁷ OPTIONAL ARB FOG LAMP KIT PART NO. 6821201. 3500440 REQUIRED WHEN FITTING 6821201 TO MODELS WITHOUT OE FOG LAMPS
- ⁸ OE FOG LAMPS OR OPTIONAL IPF FOG LAMP KIT PART NUMBER 9381FCK
- ⁹ 2010+ MODELS WITH "MILLENNIUM" OR "LIMITED" GRILLS MAY NEED MODIFICATION. PLEASE CONTACT ARB FOR DETAILS (425) 264-1391
- ¹⁰ IF FITTING 12000LB WINCH, EXTRA LONG CABLE KIT 3512050 IS REQUIRED
- ¹¹ ROCK WARRIOR EDITION TUNDRA GRILL ASSEMBLIES WILL NOT CLEAR ARB BULLBARS
- ¹² OPTIONAL ARB FOG LAMP KIT PART NO. 3500590. 3500530 REQUIRED WHEN FITTING 3500590 TO MODELS WITHOUT OE FOG LAMPS
- ¹³ 3415020K KIT INCLUDES SUMMIT BUMPER, WINCH INSTALL KIT, ARB FOG LIGHT KIT AND FOG LIGHT HARNESS.
- ¹⁴ OPTIONAL HAWSE FAIRLEAD SPACER KIT PART NUMBER 3500600 REQUIRED WHEN FITTING A HAWSE FAIRLEAD.
- ¹⁵ WARN PART NO. W89965 REQUIRED WHEN FITTING WARN ZEON PLATINUM WINCH.
- ¹⁶ WARN PART NO. W94288 ENHANCED SIGNAL KIT MAY BE NEEDED WHEN FITTING WARN ZEON PLATINUM WINCH.

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES						
YEAR	AXLE	DESCRIPTION	SHAFT	SPLINE	RATIO	PART NO.
1999-06	FRONT	7.5" DIA. RG, 10 BOLT, IFS	28 (1.1")	27	ALL	RD90
1999-06	REAR	8" DIA. RG, 12 BOLT	33 (1.31")	30	ALL	RD129
2007-18	FRONT	8" IFS, 58MM BEARING	35 (1.38")	34	ALL	RD151
2007-18	REAR	4.7 LITER ENGINE 9.5" DIA. RG	35 (1.37")	32	ALL	RD152
		5.7 LITER ENGINE 10.5" DIA RG				36

OME Suspension Next Page



OLD MAN EMU SUSPENSION SYSTEMS

MODEL	LOCATION	DESCRIPTION	TYPE	LIFT	QUANTITY	PART NO.	
2007-18	COMPLETE KITS	4.7L V8 STOCK/LIGHT LOAD (0-150LBS)	KIT	2.5"	1	OMETUN47LKS ⁴	
		4.7L V8 HEAVY LOAD (200LBS+)	KIT	2.5"	1	OMETUN47HKS ⁴	
		5.7L V8 STOCK/LIGHT LOAD (0-150LBS)	KIT	2.5"	1	OMETUN57LKS ⁴	
		5.7L V8 HEAVY LOAD (200LBS+)	KIT	2.5"	1	OMETUN57HKS ⁴	
		4.7 & 5.7L STOCK/HEAVY LOAD BP-51 KIT	KIT	2.5"	1	OMETUN57BP5 ¹⁵	
	FRONT	STOCK/LIGHT LOAD (0-150LBS)	SPRING		2.50"	1	2612
		NITROCHARGER SPORT	STRUT			2	90018
		HEAVY LOAD 4.7 LITER ENGINE (200LBS+)	SPRING		2.50"	1	2614
		NITROCHARGER SPORT	STRUT			2	90018
		HEAVY LOAD 5.7 LITER ENGINE (200LBS+)	SPRING		2.50"	1	2613
		NITROCHARGER SPORT	STRUT			2	90018
	REAR	MEDIUM LOAD (0LBS TO GVW)	SPRING		2.50"	2	CS055R ³
		NITROCHARGER SPORT	SHOCK			2	60100
	REQUIRED	FITTING KIT				1	FK32 ¹
		U BOLTS				4	OMEU53B
	OPTIONAL	BP-51 COILOVER FRONT RIGHT	SHOCK	2.5"		1	BP5190010R ⁶
		BP-51 COILOVER FRONT LEFT	SHOCK	2.5"		1	BP5190010L ⁶
		BP-51 SHOCK REAR RIGHT	SHOCK			1	BP5160020R ⁷
		BP-51 SHOCK REAR LEFT	SHOCK			1	BP5160020L ⁷
		FRONT BP-51 VEHICLE MOUNT KIT	F/KIT			1	VM80010034 ⁶
		REAR BP-51 VEHICLE MOUNT KIT	F/KIT			1	VM80010035 ⁷
		SPRING BUSH KITS WHEN USED WITH OMEGS22 SHACKLES				2	OMESB106
		SPRING BUSH KITS WHEN USED WITH FACTORY SHACKLES					SEE NOTE ²
		GREASABLE SHACKLE KIT				1	OMEGS22
		EXTRA LEAF				2	D28XL

** OME FRONT COILS CAN ONLY BE INSTALLED WITH OME NITROCHARGER STRUTS AND COIL SEATS.

¹ FK32 FITTING KIT IS A BRAKE LINE AND ABS WIRE BRACKET RELOCATION KIT AND IS A MANDATORY FITMENT.

² NEW BONDED RUBBER BUSHES ARE SUPPLIED WITH THE LEAF SPRINGS

³ TRD MODELS WITH REAR SWAYBARS MAY REQUIRE LONGER LINKS TO RETAIN SWAYBAR OPERATION.

⁴ COMPLETE KITS CONTAIN NITROCHARGER SPORT SHOCKS & STRUTS.

⁵ COMPLETE KITS CONTAIN OME BP-51 ADJUSTABLE INTERNAL BYPASS SHOCKS AND COILOVERS.

⁶ VEHICLE MOUNTING KIT PART NUMBER **VM80010034** REQUIRED WHEN FITTING **BP5190010R/L** COILOVERS.

⁷ VEHICLE MOUNTING KIT PART NUMBER **VM80010035** REQUIRED WHEN FITTING **BP5160020R/L** SHOCKS.