

LAND CRUISER 60 SERIES

ARB DELUXE BULL BARS & WINCH BARS

| YEAR | MODEL | FEATURES | WINCHES | PART NO. |
|---------|-----------|----------------------------|---------------|----------|
| 1980-89 | WINCH BAR | RECESSED INDICATORS, BLACK | XD9000, M8274 | 3410100 |

IPF LIGHTING & ACCESSORIES

| YEAR | RECOMMENDED LIGHTING |
|------|----------------------|
|------|----------------------|

| | |
|---------|---|
| 1980-89 | 800XSD, 900XSD, 900XSS, 900HIDD, 900HIDS, 868CS, 968CSG |
|---------|---|

¹IPF M002 HEADLIGHT UPGRADE HARNESS RECOMMENDED WHEN INSTALLING HIGH PERFORMANCE H4 BULBS

SAFARI SNORKEL

| YEAR | RECOMMENDED SNORKEL | PART NO. |
|------|---------------------|----------|
|------|---------------------|----------|

| | | |
|---------|----------------------|---------------------|
| 1980-89 | ALL 60 SERIES MODELS | SS60HF ¹ |
|---------|----------------------|---------------------|

¹ MODIFICATIONS MAY BE NEEDED TO THE AIR BOX. PLEASE CALL ARB FOR MORE DETAILS. (888) 427-2872

ARB SIDE STEPS

| YEAR | DESCRIPTION | PART NO. |
|------|-------------|----------|
|------|-------------|----------|

| | | |
|---------|------------------------------|---------|
| 1980-89 | SIDE PROTECTION STEPS. BLACK | 4410020 |
|---------|------------------------------|---------|

ARB AIR LOCKER LOCKING DIFFERENTIALS & ACCESSORIES

| YEAR | AXLE | DESCRIPTION | SHAFT | SPLINE | RATIO | PART NO. |
|------|------|-------------|-------|--------|-------|----------|
|------|------|-------------|-------|--------|-------|----------|

| | | | | | | |
|---------|-------|-------------------------------|------------|----|-----|--------------------|
| 1980-89 | FRONT | 12 BOLT, FULL FLOATING | 33 (1.31") | 30 | ALL | RD142 ¹ |
| | REAR | 12 BOLT, SEMI FLOATING | 33 (1.31") | 30 | ALL | RD153 ¹ |
| | | 12 BOLT, FULL FLOATING (50MM) | 33 (1.31") | 30 | ALL | RD142 ¹ |
| | | 12 BOLT, FULL FLOATING (45MM) | 33 (1.31") | 30 | ALL | RD142 ¹ |

¹ MUST USE LATE MODEL 50.00 MM (1.969") ID BEARINGS WITH THIS APPLICATION. (ARB PART No. 160116)

ARB ROOF RACKS

| YEAR | DESCRIPTION | PART NO. |
|------|-------------|----------|
|------|-------------|----------|

| | | |
|-----------|---|----------|
| 60 SERIES | 87" X 49" STEEL RACK WITH MESH FLOOR | 3800010M |
| | 87" X 49" STEEL RACK WITHOUT MESH FLOOR | 3800010 |
| | 87" X 49" ALLOY RACK WITH MESH FLOOR | 4900010M |
| | 87" X 49" ALLOY FLAT RACK | 4900060M |
| | 87" X 49" STEEL FLAT RACK | 3800240 |
| | 87" X 49" STEEL TOURING RACK FOR ROOF TOP TENT | 3800200 |
| REQUIRED | 87" X 49" FITTING KIT (ALLOY & STEEL) | 3700050 |
| | 73" X 49" STEEL RACK WITH MESH FLOOR | 3800020M |
| | 73" X 49" STEEL RACK WITHOUT MESH FLOOR | 3800020 |
| REQUIRED | 73" X 49" STEEL FLAT RACK | 3800220 |
| | 73" X 49" FITTING KIT | 3700050 |
| | 43" X 49" STEEL RACK WITH MESH FLOOR | 3800030M |
| REQUIRED | 43" X 49" FITTING KIT | 3700060 |
| OPTIONAL | WIND DEFLECTOR FOR 49" WIDE ROOF RACK (CAGED MODELS ONLY) | 3700310 |
| | HI-LIFT JACK AND SHOVEL HOLDER FOR ARB ROOF RACK | K6202 |

LAND CRUISER 60 SERIES

OLD MAN EMU SUSPENSION SYSTEMS

| MODEL | LOCATION | DESCRIPTION | TYPE | LIFT | QUANTITY | PART NO. | |
|--------------------------------|----------|--------------------------------------|--------------------------|-----------|----------------------------|----------------------------|-------|
| 60/61/62 SERIES | FRONT | GAS - STOCK/LIGHT LOAD (0-110LBS) | SPRING | 2.0" | 2 | CS003F ⁶ | |
| | | NITROCHARGER SPORT SHOCK | SHOCK | | 2 | 60009 | |
| | | GAS - HEAVY LOAD (110-240LBS) | SPRING | 2.0" | 2 | CS004F ^{1,6} | |
| | | NITROCHARGER SPORT SHOCK | SHOCK | | 2 | 60063 | |
| | | DIESEL - STOCK/LIGHT LOAD (0-110LBS) | SPRING | 2.0" | 2 | CS004F ^{1,6} | |
| | | NITROCHARGER SPORT SHOCK | SHOCK | | 2 | 60009 | |
| | | DIESEL - HEAVY LOAD (110-240LBS) | SPRING | 2.0" | 2 | CS005F ^{6,8} | |
| | | | NITROCHARGER SPORT SHOCK | SHOCK | | 2 | 60063 |
| | REAR | STOCK/LIGHT LOAD | SPRING | 3.0"/2.0" | 2 | CS017RA/B ^{2,6,9} | |
| | | NITROCHARGER SPORT - POST 1986 | SHOCK | | 2 | 60062 ³ | |
| | | NITROCHARGER SPORT - PRE 1986 | SHOCK | | 2 | 60032 ³ | |
| | | MEDIUM LOAD (0LBS - GVW) | SPRING | 3.0"/2.0" | 2 | CS004RA/B ^{2,6,9} | |
| | | NITROCHARGER SPORT - POST 1986 | SHOCK | | 2 | 60065 ³ | |
| | | NITROCHARGER SPORT - PRE 1986 | SHOCK | | 2 | 60064 ³ | |
| HEAVY CONSTANT (440LBS TO GVW) | | SPRING | 3.0"/2.0" | 2 | CS005RA/B ^{2,6,9} | | |
| | | NITROCHARGER SPORT - POST 1986 | SHOCK | | 2 | 60065 ³ | |
| | | NITROCHARGER SPORT - PRE 1986 | SHOCK | | 2 | 60064 ³ | |

| | | | |
|---------------------------------|-----------------------------|---|-----------------------|
| REQUIRED FOR INSTALLATION | SPRING BUSHING KIT | 4 | OMESB1 |
| | FRONT U BOLTS | 4 | OMEU51 ⁴ |
| | REAR U BOLTS | 4 | OMEU59B ⁴ |
| | FRONT FITTING KIT | 1 | FK01 ⁵ |
| | REAR FITTING KIT | | SEE NOTE ⁵ |
| | ANTI INVERSION KIT | 2 | FK08 ⁶ |
| | STEERING DAMPER | 1 | OMESD24 |
| OPTIONAL | FRONT GREASABLE SHACKLE KIT | 1 | OMEGS2 |
| | REAR GREASABLE SHACKLE KIT | 1 | OMEGS1 |
| | GREASABLE PIN KIT | 2 | OMEGP1 |

¹ WHEN BUMP STOP HEIGHTS EXCEED 110MM THE 4TH LEAF IN THE CS004F SPRING CAN BE REMOVED OR CS003F CAN BE USED FOR RIDE QUALITY AND TO REINSTATE DESIRED BUMP STOP HEIGHT. OMECW2 SPRING CASTER WEDGE MAY BE REQUIRED TO RESTORE POSITIVE CASTER ANGLE.

² BARN DOOR MODELS MAY REQUIRE A/A OR B/B SPRING FITMENT.

³ POST 1986 VEHICLES HAVE 19MM MOUNTING PIN AND ACCEPT SHOCK PART NO'S 60065 & 60062. PRE '86 MODELS HAVE 16MM MOUNTING PIN AND USE 60064 & 60032.

⁴ COMPARE ORIGINAL SPRING PACK TO OME SPRING PACK TO DETERMINE U BOLT.

⁵ FRONT: FK01 NOT REQUIRED IF OE U BOLTS ARE REPLACED WITH OMEU51. REAR: ONLY REQUIRED ON VEHICLES WITH RUBBER INSULATORS AROUND REAR SPRINGS. REFER TO OME FITTING MANUAL SECTION 7 GFI LAND CRUISER 60 SERIES PAGE 7 SELECTION CHART.

⁶ FK08 ANTI INVERSION KIT IS MANDATORY FITMENT IF GREASABLE SHACKLES ARE NOT FITTED.

⁷ EXTRA LEAF CAN BE FITTED FOR HEAVIER CONSTANT LOAD CARRYING. IMPORTANT: INSTALL LEAF SPRINGS WITH MILITARY WRAP AT THE FIXED END.

⁸ CS005F IS A MODULAR SPRING USING CS004F SPRING & 3A/BXL LEAF.

⁹ NORTH AMERICAN MODELS DO NOT LEAN SO THE SAME SPRING SHOULD BE USED ON BOTH DRIVER AND PASSENGER SIDES, CHOOSE TWO "A" SPRINGS FOR A 3" LIFT OR CHOOSE TWO "B" SPRINGS FOR A 2" LIFT.